

## Beverage Stabilization

### SIHA® CelluStab



**SIHA CelluStab stabilizer from Eaton's Begerow Product Line is a special product used for the prevention of tartrate precipitation in bottled wines.**

#### Product Characteristics

The active ingredient is an Carboxymethylcellulose (CMC), which is a water soluble molecule derived from cellulose, that has the ability to trap tartaric acid and prevents it from crystallizing. The stabilization effect is not affected e.g. heat and filtration. The addition of CMC has no influence on the organoleptic characteristics and the color of the wine.

#### Application

##### Quantities

The European Commission regulation establishing the new implementing rules on oenological practices is effective since the Aug 1, 2009, officially allowing the addition of CMC to wines for tartaric stabilization ((EC) No. 606/2009 to implement the Council Regulation (EC) No. 479/2008).

Max. quantity: 0.83 lb/1,000 gal (100 mg/l)

##### Addition to Wine

SIHA CelluStab stabilizer is offered as a 5% (41.72 lb/100 gal (50 g/l)) low viscosity solution.

This equates a max. dosage of the product of 25.60 fl oz/100 gal (200 ml/hl).

Before the addition to the tank, we recommend to dilute the solution in wine. Further, it is important that, during the addition, the agitator is stirring continuously, to have a homogeneous dispersion.

##### Special Note

We recommend making preliminary and stabilization tests ensure to have the right dosage. Please note: if the saturation temperature is higher than 68 °F (20 °C), there is a risk that the stabilization is not sufficient under certain conditions. In case of usage in red wines, there is a possibility of interaction with coloring matter that can lead to the formation of haze and/or precipitate. SIHA CelluStab stabilizer can also react with Lysozym and protein instable wines.

SIHA CelluStab stabilizer should be added at least 4 – 5 days before filtration. A longer waiting period improves the filter index. Otherwise, a clogging of the membranes during bottling can occur.

The final adjustment of sulphur in the Wine has to be added after adding SIHA CelluStab stabilizer.

#### Safety

When used and handled correctly, there are no known unfavorable effects associated with this product.

Further safety information can be found in the relevant Material Safety Data Sheet, which can be downloaded from our website.

#### Storage

SIHA CelluStab stabilizer should be kept in closed containers in a cool and dry place.

It is stabilized with SO<sub>2</sub>, however open containers should be used up quickly.

Protect from frost.

#### Delivery Information

SIHA CelluStab stabilizer is sold under article no. 64.209 and is available in the following package sizes:

1.32 gal (5 l) PE canister

6.6 gal (25 l) PE canister

HS Customs Tariff: 3912 31 00

#### Certified Quality

SIHA CelluStab stabilizer is monitored regularly during the production process to ensure consistently high quality. These inspections cover technical function criteria as well as compliance with the law governing the production and sale of foodstuffs. Strict controls are also carried out immediately before and during final packaging.

**North America - HQ**

44 Apple Street,  
Tinton Falls, NJ 07724  
Toll Free: 800 656-3344  
(North America Only)  
Voice: +1 732 212-4700

**Europe/Africa/Middle East**

Auf der Heide 2  
53947 Nettersheim, Germany  
Voice: +49 2486 809-0

**Internormen Product Line**

Friedensstraße 41  
68804 Altlussheim, Germany  
Voice: +49 6205 2094-0

**Begerow Product Line**

An den Nahewiesen 24  
55450 Langenlonsheim, Germany  
Voice: +49 6704 204-0

**Brazil**

Av. Julia Gaioli, 474 - Bonsucesso  
07251-500 - Guarulhos  
Brazil  
Voice: +55 11 2465 8822

**China**

No. 7 Lane 280 Linhong Road,  
Changning District,  
Shanghai 200335, China  
Voice: +86 21 5200 0422

**Singapore**

4 Loyang Lane #04-01/02  
Singapore 508914  
Voice: +65 6825 1668

For more information, please e-mail us at [filtration@eaton.com](mailto:filtration@eaton.com) or visit us online at [eaton.com/filtration](http://eaton.com/filtration) for a complete list of Eaton's filtration products.

Not all products in Eaton's Begerow Product Line are available in all regions. Please contact your local Eaton office to determine availability.

© 2013 Eaton Corporation. All Rights Reserved. All trademarks and registered trademarks are the property of their respective owners.

All information and recommendations appearing in this brochure concerning the use of products described herein are based on tests believed to be reliable. However, it is the user's responsibility to determine the suitability for his own use of such products. Since the actual use by others is beyond our control, no guarantee, expressed or implied, is made by Eaton as to the effects of such use or the results to be obtained. Eaton assumes no liability arising out of the use by others of such products. Nor is the information herein to be construed as absolutely complete, since additional information may be necessary or desirable when particular or exceptional conditions or circumstances exist or because of applicable laws or government regulations.



*Powering Business Worldwide*

EN  
1 B 5.6.4  
03-2013